

## Alternator Regulator/Rectifier - Installation

1. Reconnect the two electrical connectors to the alternator rectifier as noted for removal.
2. Position the alternator rectifier to its mounting bracket below the ABS modulator, secure with the two fixings and tighten to **4 Nm**.
3. Refit the ABS modulator cover fit the shouldered washers and tighten its fixings to **4 Nm**.
  - Reconnect the battery, positive (red) lead first (see [Battery - Installation](#)) and tighten the terminals to **4.5 Nm**.
  - Refit the seat (see [Seat - Installation](#)).